

**FILLING HOLES & DEEP SCRATCHES**



**REPAIRING CRACKS**



**BONDING/GLUING**



**01 DEGREASE & CLEAN THE SURFACE WITH TSP 600**

Make sure you ALWAYS wear gloves and that both sides of the surface are cleaned and degreased. DO NOT degrease after this step.



**02 V GROOVE THE AREA WITH A COARSE ABRASIVE P80 or coarser**



**03 PIN HOLES ALONG EACH SIDE OF THE REPAIR in the V groove area**



**04 ADD A VAPOR OF FINIXA PRIMER TSP 030**



**05 APPLY THE PLASTIC REPAIR WITH THE GUN ON THE REINFORCEMENT CANVAS**  
Keep nozzle in product to prevent air bubbles



**06 PRESS THE PRODUCT FROM THE INSIDE OUT TO THE AESTHETIC SIDE OF THE REPAIR SPOT THRU THE HOLES.**



**07 FINISH OFF THE AESTHETIC SIDE USING THE CONTOUR CANVAS (PLI 16)**  
Optionally : use the spreader to even out the surface



**08 SAND THE SURFACE CREATED BY THE PLASTIC REPAIR**

Finish off the repair with Finixa GAPOL if needed.

